


#### **INSTALLATION INSTRUCTIONS:**

REFER TO APPROPRIATE MOUNTING PLATE TO INSTALL WALL MOUNTING PLATE CORRECTLY.


- A- ROUGH-IN WASTE AND SUPPLY LINE DURING -MP1 (1) INSTALLATION OR PRIOR TO MOUNTING FIXTURE.
- B- CAREFULLY REMOVE FIXTURE FROM PACKAGING MATERIAL AND COVER TO PREVENT SCRATCHING OR DAMAGE.
- C-REMOVE BOTTOM ACCESS PANEL (2). ENSURE PUSHBUTTON (3), P-TRAP (4), BUBBLER AND ALL TUBING CONNECTIONS HAVE NOT BECOME LOOSE DURING SHIPPING. CORRECT IF NECESSARY.
- D- ALIGN FIXTURE MOUNTING POINTS WITH STUDS (5) AND SLIDE FIXTURE TO FINISHED WALL WITH NUTS AND WASHERS PROVIDED.



- E- MAKE UP CONNECTION TO 1-1/4" OD WASTE TRAP ASSEMBLY 6 PROVIDED.
- F- FLUSH SUPPLY LINES THOROUGHLY BEFORE CONNECTING SUPPLY INLET (7). MAKE UP CONNECTIONS TO 1/4" OD COPPER TUBE INLET.
- G- TEST OPERATION OF BUBBLERS BY DEPRESSING BUTTONS AND ADJUST THE FLOW RATE AS REQUIRED. CHECK ALL CONNECTIONS AND WASTE PIPING FOR LEAKS. CORRECT IF PRESENT.
- H-RE-INSTALL BOTTOM ACCESS PANEL (2).

#### NOTE:


STANDARD VALVE SHOWN. FOR THE OPTIONAL -FRA1 FREEZE RESISTANT VALVE REFERENCE DRAWING # 9938-330-001.






ROUGH-IN FOR 3/8" OD PUSH-IN SUPPLY INLET, STRAIGHT STOP RECOMMENDED. \*1/4" NCT x 2" LONG TUBE STUB OUT PROVIDED.

ROUGH-IN FOR 1-1/4" OD P-TRAP WASTE OUTLET.





#### **INSTALLATION INSTRUCTIONS:**

- A-PLATE ① INTENDED TO BE RECESSED FLUSH WITH SUPPORT FRAMING ② PROVIDED BY INSTALLER. FRAME & BLOCK OUT SUPPORT USING DIMENSIONS SHOWN. FRAME SHOULD SUPPORT 300 LBS MINIMUM.
- B-MOUNTING PLATE ① IS 1/4" THICK AND INCLUDES 12, 1/2" DIAMETER PUNCHING FOR ANCHORING HARDWARE BY OTHERS.
- C-STRIKE A HORIZONTAL CHALK LINE TO LOCATE BOTTOM MOUNTING HOLES ③. REFERENCE DISCHARGE HEIGHT REQUIREMENTS FOR YOUR MODEL AND FACILITY TO DETERMINE CORRECT HEIGHT AT FINISHED FLOOR (AFF).
- D-AFTER POSITIONING PLATE CORRECTLY, FIX PLATE TO WALL USING APPROPRIATE, INSTALLER PROVIDED ANCHORING HARDWARE 4.
- E-MAKE UP APPROPRIATE SUPPLY (5) AND WASTE (6) ROUGHS THROUGH MOUNTING PLATE OPENINGS. A STRAIGHT SUPPLY STOP IS RECOMMENDED.
- F-REFER TO FIXTURE INSTALLATION SHEETS TO LOCATE 5/16" THREADED STUDS MOUNTING HARDWARE AND THREAD STUDS (7) THRU PLATE SO THAT A MINIMUM OF 1-1/4" OF THREAD PROJECTS BEYOND THE FINISHED WALL MATERIAL.
- G-PROTECT THREADED STUDS (7), SUPPLY (5) AND WASTE (6) ROUGHS WHILE FINISHING WALL.

DRAWING NUMBER



### -MP1 WALL MOUNTING PLATE

MANUFACTURE DATE

JANUARY 2006


TO PRESENT

DATE ISSUED

**09/28/05**DATE REVISED

03/02/16

9938-375-001



				<b>*</b>				
1	6154-035-002 STONE CANT	LEVER PUSHBUTTON ASSEMBLY	6	2590-610-001	S/T NON-METERING AI	R-CONTROL VALVE		
2	2566-0019-000 PUSHBUTTON	DIAPHRAGM	7		WATER DIAPHRAGM ASS	SEMBLY		
3	7000-012-001 STAINLESS S	TEEL BUBBLER	8	7000-021-001				
4	0152-006-000 ALLEN FLAT	HEAD SCREW	9	7000-015-000	1-1/4" OUTER DIAMETI	ER P-TRAP		
5	7000-006-000 FLAT DRAIN	ADAPTER GASKET	10	0112-002-000	CENTER REJECT ALLEN	BUTTON HEAD SCREY		
ITEM	PART NUMBER	DESCRIPTION	ITEM	PART NUMBER	DESCRI	PTION		
MURDOCK-SUPER SECUR P.O. Box 3527 Industry, CA 91744 15125 Proctor Ave Industry, CA 91746  SQUARE OUTDOOR STONE WALL MOUNTED DRINKING FOUNTAIN								
		MANUFACTURE DATE		DATE ISSUED	DRAWING NUM	BER		

11/01/05

04/20/16

DATE REVISED

9938-210-500

**JANUARY 2006** 

TO PRESENT


716

## PUSH PAD / PUSH BUTTON FRU FREEZE RESISTANT DRINKING FOUNTAINS NON-METERING AIR-CONTROLLED VALVE - (DIRECT ACTING)

#### CONDITION:

#### **SOLUTION:**

#### NO WATER FLOW:




- 1.1 Check water main supply open.
- 1.2 Inspect checkstops open.
- 1.3 Inspect checkstop strainer for debris clean.
- 1.4 Check 1/8" O.D. tubing and fittings for leaks.
- 1.5 Check pushbutton air diaphragm for holes.
- 1.6 Check servomotor diaphragm center hole for blockage.

## WATER DRIPS / WILL NOT SHUT OFF:




- 2.1 Check servomotor diaphragm offset hole for debris.
- 2.2 Check servomotor seat for build-up or damage.
- 2.3 Check servomotor seat o-ring for damage.
- 2.4 Check servomotor plate and diaphragm for obstruction.

#### **REDUCED WATER FLOW:**



- 3.1 Check water main supply for 20 psig minimum flow pressure.
- 3.2 Check valve riser tubing for crimping.
- 3.3 Inspect checkstop strainer for debris clean.
- 3.4 Check valve flow control for blockage clean.
- 3.5 Inspect bubbler for debris clean.

#### PREMATURE WATER SHUTOFF:



- 4.1 Check 1/8" O.D. tubing and fittings for leaks.
- 4.2 Check pushbutton air diaphragm for holes.

Refer to Air—Controlled Valve Maintenance Detail on drawing # 9940—203—001 for —FRA\_ Above Ground units and on drawing # 9940—204—001 for Stone & —FRU\_ Below Ground units to locate solutions above.

MURDOCK-SUPER SECUR TITLE
P.O. Box 3527 Industry, CA 91744
15125 Proctor Ave Industry, CA 91746
Phone: (800) 591-9880
www.murdock-supersecur.com

MANU

### FRU FREEZE RESISTANT FOUNTAIN VALVE MAINTENANCE INSTRUCTIONS

JANUARY 2006 To present

MANUFACTURE DATE

DATE ISSUED

10/20/05

DATE REVISED


03/15/16

DRAWING NUMBER

9940-202-001



# PUSH PAD / PUSH BUTTON BELOW GROUND FREEZE RESISTANT DRINKING FOUNTAINS NON-METERING AIR-CONTROLLED VALVE - (DIRECT ACTING)



#### **CHECKSTOP STRAINER - SERVOMOTOR DETAIL**

Refer to drawing #9940-202-001 for Valve Maintenance Instructions numbered solutions detailed above.

	MURDOCK-SUPER SECUR P.O. Box 3527 Industry, CA 91744 15125 Proctor Ave Industry, CA 91746	NON-METERING FRU AIR-C	CONTROLLED VALVE MAIN	ITENANCE INSTRUCTIONS
mure	Phone: (800) 591-9880 www.murdock-supersecur.com	MANUFACTURE DATE	DATE ISSUED	DRAWING NUMBER
		JANUARY 2006	12/07/05	
3/4		TO PRESENT	DATE REVISED 03/15/16	9940-204-001