⋖

NONE

3-24-03

APPROVED BY: 딩

снескер ву

ರ

AND CHANGE WITHOUT NOTICE

TO MANUFACTURERS

5619BS

FIGURE NUMBER

2

4


LOCATION

Actuator Cartridge

Assembly

** 13

GUARDIAN DUAL CHECK HYDRANT PARTS LIST



Installer is responsible for providing a 100% watertight positive seal at the hydrant to wall interface. Seal all the flange with an appropriate sealant recommended by a sealant manufacturer. NOTE: Jay R. Smith does not warrant the performance or life expectancy of the sealant material.

8

10

HYDRANT PARTS LIST										
NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION			
1b 1c 2	Casing Assembly Head Casing Valve Housing Wall Plate Assembly Key Wall Plate Securing Screw (5) Wall Plate Gasket Stationary Operator Piece	7 8 9 10 11 12 12a 12b 12c	**Spring (2)		**Valve Body **Actuator O-Ring (2) **Nylon Thrust Spacer	13f 13g 13h 13j 13k 13m	**Nylon Thrust Washer **Rotating Ceramic Disc **Fixed Ceramic Disc **O-Ring **O-Ring Gasket Retainer **Rubber Seal			

					WEIGHT POUNDS	VOLUME CUBIC FEET	FIGURE NUMBER
Α	4-5-18 Added Note		TBW	BW			5619BS
REV.	DATE	DESCRIPTION	BY	CKD. BY			00.000